






INSPECTION PROCEDURE 3: The Compressor does not Work.

A/C Compressor Assembly Circuit



W8G55M009A



FUNCTION

Compressor that recovers the refrigerant, which evaporated in the evaporator and became a high-temperature and high-pressure gas, and turns it into liquid again.


PROBABLE CAUSES

- Insufficient refrigerant
- Malfunction of connector.
- Malfunction of the harness (A/C compressor circuit is open/shorted to ground)
- Malfunction of the A/C pressure sensor.
- Malfunction of the A/C compressor.
- Malfunction of the A/C compressor clutch relay.
- Malfunction of the A/C-ECU.

DIAGNOSIS

Required Special Tools:

- MB991223: Harness Set
- MB992006: Extra Fine Probe
- MB991658: Test Harness Set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A



STEP 1. Using scan tool MB991958, diagnose the CAN bus line.

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect the Scan Tool (M.U.T.-III) P.55A-6."
- (2) Turn the ignition switch to the "ON" position.
- (3) Diagnose the CAN bus line.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

Q: Is the CAN bus line found to be normal?

YES : Go to Step 2.

NO : Repair the CAN bus lines (Refer to GROUP 54C, precautions on how to repair the CAN bus lines P.54C-16).

STEP 2. Using scan tool MB991958, read the diagnostic trouble code.

Check if an A/C-ECU DTC is set.

- (1) Connect scan tool MB991958 to the data link connector.
- (2) Turn the ignition switch to the "ON" position.
- (3) Check if the DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

Q: Is the DTC set?

YES : Refer to Diagnostic Trouble Code Chart P.55A-8.


NO : Go to Step 3.

STEP 3. Check A/C compressor assembly connector B-17 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Is A/C compressor assembly connector B-17 in good condition?

YES : Go to Step 4.

NO : Repair or replace the connector. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.



STEP 4. Check the A/C compressor clutch operation.

Connect the compressor connector terminal to the battery positive (+) terminal and ground the battery's negative (-) terminal to the compressor unit. At that time, the A/C compressor clutch should make a definite operating sound.

Q: Can the sound (click) of the A/C compressor clutch operation be heard?

YES : Go to Step 5.

NO : Replace the compressor magnet clutch.

STEP 5. Check A/C compressor clutch relay connector A-13X for loose, corroded or damaged terminals, or terminals pushed back in the connector.


Q: Is A/C compressor clutch relay connector A-13X in good condition?

YES : Go to Step 6.

NO : Repair or replace the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

STEP 6. Check the A/C compressor clutch relay continuity.

Follow the table below to check the A/C compressor clutch relay for continuity.



BATTERY VOLTAGE	TESTER CONNECTION	SPECIFIED CONDITION
Not applied	3 – 4	Open circuit
<ul style="list-style-type: none"> Connect terminal 2 to the positive battery terminal Connect terminal 1 to the negative battery terminal 	3 – 4	Less than 2 ohms

Q: Is the A/C compressor clutch relay in good condition?

YES : Go to Step 7.

NO : Replace the A/C compressor clutch relay.

STEP 7. Check engine control module connector B-109 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Is engine control module connector B-109 in good condition?

YES : Go to Step 8.

NO : Repair or replace the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).


STEP 8. Measure the voltage at A/C compressor assembly connector B-17.

- (1) Disconnect A/C compressor assembly connector B-17 and measure the voltage at the wiring harness side.
- (2) Disconnect powertrain control module connector B-109 and ground harness side terminal No.102.
- (3) Turn the ignition switch to the "ON" position.
- (4) A/C compressor assembly connector B-17 terminal 1 and ground.
 - The measured value should be approximately 12 volts (battery positive voltage).

Q: Is the measured voltage approximately 12 volts?

YES : Go to Step 13.

NO : Go to Step 9.




STEP 9. Measure the voltage at A/C compressor clutch relay connector A-13X.

- (1) Disconnect A/C compressor connector A-13X and measure the voltage at the relay box side.
- (2) Turn the ignition switch to the "ON" position.
- (3) Measure the voltage between terminal 4 and ground.
 - The measured value should be approximately 12 volts (battery positive voltage).
- (4) Measure the voltage between terminal 2 and ground.
 - The measured value should be approximately 12 volts (battery positive voltage).

Q: Is the measured voltage approximately 12 volts?

YES : Go to Step 11.

NO : Go to Step 10.



STEP 10. Check the wiring harness between A/C compressor clutch relay connector A-13X (terminals 2 and 4) and the fusible link (36).

Q: Is the wiring harness between A/C compressor clutch relay connector A-13X (terminals 2 and 4) and the fusible link (36) in good condition?

YES : It can be assumed that this malfunction is intermittent. Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points –How to Cope with Intermittent Malfunctions [P.00-13](#).

NO : Repair the wiring harness. Check that the A/C works normally.

STEP 11. Check the wiring harness between A/C compressor clutch relay connector A-13X (terminal 3) and A/C compressor assembly connector B-17 (terminal 1).

NOTE: Also check intermediate connector A-10 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If intermediate connector A-10 is damaged, repair or replace the connector as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Is the wiring harness between A/C compressor clutch relay connector A-13X (terminal 3) and A/C compressor assembly connector B-17 (terminal 1) in good condition?

YES : Go to Step 12.



NO : Repair the wiring harness. Check that the A/C works normally.

STEP 12. Check the wiring harness between powertrain control module connector B-109 (terminal 102) and A/C compressor clutch relay connector A-13X (terminal 1).

Q: Is the wiring harness between powertrain control module connector B-109 (terminal 102) and A/C compressor clutch relay connector A-13X (terminal 1) in good condition?

YES : It can be assumed that this malfunction is intermittent. Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points –How to Cope with Intermittent Malfunctions [P.00-13](#).

NO : Repair the wiring harness. Check that the A/C works normally.



STEP 13. Check the refrigerant temperature switch.

⚠ CAUTION

Do not heat more than necessary.

- (1) Dip the metal part of the cooling temperature switch into engine oil and increase the oil temperature using a gas burner or similar.

- (2) When the oil temperature reaches the standard value, check that resistance is supplied between the terminals.

Standard value:

ITEM	TEMPERATURE
Less than 2 ohms	Slightly below 155° C (311° F)
No continuity	155° C (311° F) or more

NOTE: When the oil temperature is 155° C (311° F) or more and there is no continuity, the resistance will not be 2Ω or lower until the oil temperature reduces to 125° C (257° F) or less.

Q: Is the refrigerant temperature switch operating properly?

YES : Go to Step 14.

NO : Replace the refrigerant temperature switch. Check that the A/C works normally.

STEP 14. Replace the A/C-ECU.

Q: Does the A/C operate normally?

YES : No action is necessary and testing is complete.

NO : Replace the powertrain control module. Check that the A/C works normally.