



3. Screw in the special tool MD998738 until it comes in contact with the timing belt tensioner arm.

4. Gradually screw in the special tool MD998738. Then align the timing belt tensioner adjuster rod set hole A with the timing belt tensioner adjuster cylinder set hole B.